

# **DK387 Rhino-Rack** VA, DA, Euro & HD crossbar instruction


***IDENTIFICATION CHART***





***VA crossbar***











***DA crossbar***



***EURO crossbar***



***HD crossbar***

| | | | ***FRONT CROSSBAR*** | | | | | | ***REAR CROSSBAR*** | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | |  | |  ***VA*** |  ***DA*** ***EURO*** |  ***HD*** |  |  | |  ***VA*** |  ***DA*** ***EURO*** |  ***HD*** |  |
| **Vehicle** | **Date** | **Crossbar** | **Front Right Pad/ Clamp** | **Front Left Pad/ Clamp** | **Measurement strip length per side** | **Measurement strip length per side** | **Measurement Distance ( x )** | **Foot plate arrow direction** | **Rear Right Pad/ Clamp** | **Rear Left Pad/ Clamp** | **Measurement strip length per side** | **Measurement strip length per side** | **Measurement Distance ( x )** | **Foot plate arrow direction** |
| Mazda 6 4dr sedan GJ | 12/12- | 1260mm | M282 SUB0369 | M281 SUB0369 | 177mm | 64mm | 1002mm / 39,29/64” | OUT | M284 SUB0513 | M283 SUB0513 | 151mm | 38mm | 950mm / 37,25/64” | OUT |
| | USA 13- | | Pad Arrow Forward | | | | | | Pad Arrow Forward | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |


# **DK387 Rhino-Rack** VA, DA, Euro & HD crossbar instruction


**Measurement A**: CENTRE of door jamb to CENTRE arrow of leg foot plate.

**Measurement B**: CENTRE of Front leg foot plate arrow to CENTRE of Rear leg foot plate arrow.

**Carrying capacity:** Roof rack is rated to 75kg. Please refer to manufacturers handbook for your vehicles maximum roof load capacity. Always use the lower of the two figures.

If your vehicle is not listed on this fitting instruction please refer to your countries Rhino-Rack web site for the latest information.




| VEHICLE | Date | | Measurement A | Measurement B | Load Rating (includes racks 5kg/ 11lbs) |
|---|---|---|---|---|---|
| Mazda 6 4dr sedan GJ | 12/12- | USA 13- | 200mm / 7,7/8” | 700mm / 27,9/16” | 75kg / 165lbs |
| | | | | | |